



CLOVER
RETURNS MANAGEMENT
SOLUTIONS

BH53602V CERTIFIED-REFURBISHED USER MANUAL

Important Information About Your Refurbished Product

Notice to Customers: This product has been refurbished by Clover Environmental Solutions, LLC dba Clover Returns Management Solutions. We are committed to providing high-quality refurbished household products to meet your needs.

Terms and Conditions: Any terms and conditions set forth in the attached original OEM documentation may not apply to this remanufactured item. For the specific terms applicable to your purchase, please refer to the documentation provided at the time of purchase or visit www.refurbproductsupport.com

Additional Information:

- **Safety Notice:** Ensure you follow all safety instructions provided in the OEM documentation as they remain applicable to the safe operation of this remanufactured product.
- **Recycling and Disposal:** For information on proper disposal or recycling of this product please visit the manufacturer's website.

Contact Us: If you have any questions or concerns about your refurbished product, please reach out to us via:

Website: www.refurbproductsupport.com

Email: productsupport@cloveres.com

Phone: (844) 745-0760

This cover sheet is being provided to ensure clarity regarding the status and support of your refurbished product. The attached OEM documentation is provided for reference only.

Hoover BH53602V Black and Decker Car Vacuum Cleaner Remanufactured User Manual



Contents

[1 Hoover BH53602V Black and Decker Car Vacuum Cleaner](#)

[2 GETTING STARTED](#)

[2.1 USING YOUR PRODUCT](#)

[2.2 EMPTYING THE DIRT CUP](#)

[2.3 TOOLS FOR EVERY MESS](#)

[2.4 PRO TIPS](#)



Hoover BH53602V Black and Decker Car Vacuum Cleaner



GETTING STARTED

Fully assemble product prior to use.

1


Charge battery.



Fully charged

2

Connect the hand vacuum to the extension wand until it clicks into place.



3

Insert battery.




USING YOUR PRODUCT

USING YOUR PRODUCT



1 Turn power on. The unit starts in default mode which provides the optimal balance of runtime and power.



2 Press “-” to increase runtime. Great for hard floors and everyday messes.



3 Press “+” to increase suction. Ideal for more embedded messes.


EMPTYING THE DIRT CUP



1 First remove battery pack, then pinch lever and remove dirt cup.



2 Hold over trash can and press the dirt cup release to empty.



3 Fit the dirt cup onto the hooks, then rock it up into the handheld so it secures into place.

TOOLS FOR EVERY MESS

WARNING: To avoid serious personal injury, always remove the battery pack from the product when connecting or disconnecting accessories.



2-in-1 Dusting Brush /Crevice Tool

Clean crevices and hard to reach areas. The soft bristle attachment is ideal to remove dust on base boards and blinds.



Motorized Pet Tool

Remove stubborn pet hair and embedded dirt on upholstery, stairs, and in your car.



Powered Extension Hose

Attach accessories to extend reach for added versatility and convenience.

PRO TIPS

FOR BEST EXPERIENCE

Charge the Battery and empty the dirt cup after each use.

TO CLEAN FILTER

Rinse with warm water and let dry for 24 hours before reinstalling. Install filter cover before reattaching the dirt cup.

FOR ABOVE FLOOR CLEANING

Connect attachments to either the handheld or the end of the extension wand to clean up high.